

**Only use this diagram if you are replacing the factory spring perch.  
Keep the factory wedge with stock spring perch if you do not use this diagram.**

